



1. Bank work crew mans the ropes.



2. Ropes extend to circle under AquaDam® and back to anchor pipe. On bank the AquaDam® begins filling.



3. Ropes keep the AquaDam® from unrolling. Water head builds inside.



4. Unroll and fill... unroll and fill... unroll and fill... keeping continuous head inside.



5. San Juan River. Main channel is completely blocked off.



6. This AquaDam® is big! Made with over 70,000 gallons of water!